



Reklamní LED řádek


1. Připojte LED panel do sítě
2. V telefonu si zapněte aplikaci „Obchod Play“
3. Vyhledejte aplikaci „LedArt“ a zvolte „Nainstalovat“




4. Nyní si v telefonu otevřete Nastavení – Připojení- Wifi a najděte si wifi LED panelu (wifi bývá v takovémto tvaru W00-xxxxxxxxxx)
5. Heslo této wifi je 88888888 (po zvolení se může objevit nápis, že internet není dostupný, toto ignorujte)



6. Vraťte se na seznam instalovaných aplikací a spusťte aplikaci LedArt



7. Pospuštění se objeví čistá obrazovka s tlačítkem „New display“ po stisknutí se zobrazí připojený panel (W00-xxxxxxxxxx) a tlačítko „Add“...



8. Po stisknutí tlačítka „Add“ se zobrazí nastavení řádku (viz. Foto)


The screenshot shows a mobile application interface for configuring a new display. The title bar is blue and contains a back arrow, the text 'New display', and a 'Sync' button. The main content area is light gray and contains several sections:

- Screen name:** A text input field containing 'Screen3'.
- Display size:** A table with two rows: 'Width' with value '96' and 'Height' with value '16'.
- Device model:** A dropdown menu showing 'W series / E series' with a right-pointing arrow.
- Color level:** A list of three options: 'Single color' (selected with a blue radio button), 'Dual color', and 'Full color'.
- Gray level:** A row of four buttons: 'N/A' (selected and highlighted in light blue), '4', and '8'.
- Double-sided screen:** A toggle switch labeled 'Enable double-sided screen' which is currently turned off.

At the bottom of the screen is a large blue button labeled 'OK'. The very bottom of the image shows the standard Android navigation bar with three icons: a home button, a back button, and a recent apps button.

9. Stiskněte „OK“

10. Nyní již můžete začít psát své texty a upravovat typ a rychlost pohybu



11. Vaše texty přenesete do panelu stisknutím tlačítka „Send“